

Is the unit installed correctly?

Suitable Installation Position

Isn't there anything which prevents ventilation or obstructs operation in front of the indoor unit ? Do not install the unit following place .

Inflammable gases may leak .

Oil splashes a lot .

In case where the unit is used in such places as poisonous or sultry gases are generated or seaside district exposed to sea breezes corrosion may cause malfunction . Consult with your distributor .

Air conditioner body and remote controller must be 1 m or more away from a TV or a radio .

Drain the dehumidified water from the indoor unit to a place which drains well .

Pay attention to operation noise

● When installing the unit , choose a place which can stand the weight of the unit well and does not increase the operation noise or vibration . Especially where there is a possibility that vibration be transmitted to the house , fix the unit by inserting attached vibration -proof pads between the unit and fittings .

● Choose the place where hot air and operation noise from the outlet of the outdoor unit do not annoy the neighborhood .

● Things left near the outlet and inlet of the outdoor unit cause malfunction or increased operation noise . Do not leave obstacles near the outlet and inlet .

● If irregular sound is heard during operation , consult with your distributor .

Inspection and Maintenance

According to the service conditions and operating environment , the inside of the air conditioner will become dirty after several seasons (3 to 5years) of service , resulting in decreased operating performance .Inspection and maintenance are recommended in addition to usual cleaning (The air conditioner can be used for a longer period and without anxiety .)

As to inspection and maintenance , consult your dealer or any one of business offices of dealing companies .(Service charge is required in this case .)

We recommend to perform inspection and maintenance during an off seasons.