

## 2-Important safety instructions

### PLEASE NOTE

**You must always observe some basic precautions when using your wine cabinet, including:**

Only use your wine cabinet for the use intended, as described in this guide.

Never unplug the wine cabinet by pulling on the power cord, Grip the plug firmly and pull straight out to remove from wall socket.

Immediately repair or replace any worn or damaged cord, never use a cord that is split or which shows signs of wear along its length or on its ends.

Do not allow children to climb on. Sit on or stand on the wine cabinet, nor hang from its shelves, they could damage the wine cabinet and injure themselves seriously,